Cooler Master Products: Limited Warranty

This document describes the warranty terms for all Cooler Master product sold in Australia

For Australia only:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. (Cooler Master Technology Inc., 8F., No. 788-1, Zhongzheng Rd., Zhonghe Dist., New Taipei City 23586, Taiwan (R.O.C.).)
Telephone: +886-2-2225-3517 (standard international call charges apply.)

Who the Warranty Protects:

This Warranty is valid to the original purchaser only.

What the warranty protects:

This warranty is valid only for the Cooler Master Products distributed by authorized dealer(s) in Australia. Please contact Cooler Master for warranty information and services:
• Cooler Master Support: account.coolermaster.com

What Is and Is Not Covered

It is important to note that our warranty is not an unconditional guarantee for the duration of the Program. Any replaced parts become the property of Cooler Master. The Program does not apply to the software component of a product or a product which has been damaged due to accident, misuse, abuse, improper installation, usage not in accordance with product specifications and instructions, natural or personal disaster, or unauthorized alterations, repairs or modifications.

The Program does not cover any events such as below:
• Any damages unrelated to manufacturing defects.
• Any unsuitable environment or use of the product in Cooler Master Opinion.
• Any product which has been modified without official permission from Cooler Master, or on which the serial number or warranty sticker has been defaced, modified, or removed.

Damage, deterioration or malfunction resulting from:
• Accident, abuse, misuse, neglect, fire, water, lightning, or other acts of nature, commercial or industrial use, unauthorized product modification or failure to follow instructions included with the product.
• Third party products using Cooler Master Components will not be covered by warranty. See your vendor or the manufacturer for information about servicing.
• Repair or attempted repair by anyone not authorized by Cooler Master, Inc.
• Any shipment damages (claims must be made with the carrier).
• Unauthorized repairs to a Cooler Master product will void the warranty offered by the Program. Cooler Master reserves the right to refuse to service any product which has been altered, modified or repaired by non- Cooler Master Service personnel.
• Cooler Master does not warrant that this product will meet your requirements. It is your responsibility to determine the suitability of this product for your purpose.
• Removal or installation charges.
• You are responsible for the cost of shipping the product to Cooler Master. Cooler Master pays the cost of returning a product to you.
• Cooler Master reserves the right to replace the product with a service product at their sole discretion at any time.
• Product malfunction or damage resulting from liquids or moisture.
• All accessories that malfunction due to physical damage such as: USB cables, extension cables, adapter cables, adapters, power cords, screws, retention brackets, ear cups, and all other similar accessories.

Limitation of implied warranties:

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, WHICH EXTEND BEYOND THE DESCRIPTION CONTAINED HEREIN INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Exclusion of damages

COOLER MASTER'S LIABILITY IS LIMITED TO THE COST OF REPAIR OR REPLACEMENT OF THE PRODUCT. COOLER MASTER SHALL NOT BE LIABLE FOR:
• DAMAGE TO OTHER PROPERTY CAUSED BY ANY DEFECT IN THE PRODUCT, DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE OF THE PRODUCT, LOSS OF TIME, LOSS OF PROFITS, LOSS OF BUSINESS OPPORTUNITY, LOSS OF GOODWILL, INTERFERENCE WITH BUSINESS RELATIONSHIPS OR OTHER COMMERCIAL LOSS, EVEN IF ADVISED OF THEIR POSSIBILITY OF SUCH DAMAGES.
• ANY OTHER DAMAGES, WHETHER INCIDENTAL, CONSEQUENTIAL OR OTHERWISE
• ANY CLAIM AGAINST THE CUSTOMER BY ANY OTHER PARTY

Warranty Information:

If the goods is found with reasonable defect within the period of (refer to Table A.,) starting on the first day of purchase (with proof of invoice), this is what you must do, to claim the warranty from the above address.

Procedures:

1. Consumers should return to the shop where he/she has bought the goods, After confirming with the shop with a valid invoice, they may approach the distributor for RMA claim.
2. After confirmed by the distributor that the goods was damaged due to natural causes, replacement and repair will be done by distributor (including brand new or refurbished goods)
3. All faulty goods must return to the distributor, expenses for returning the faulty goods will be covered by the consumer, and distributor will cover the cost involved in the transporting of parts or repaired goods to the consumer.

Regarding all the expenses incurred in making the claim, and this is how you would claim:
1. Within the valid warranty date, starting from the first day of issuing invoice, Retail shops will assist in confirmation with distributor for the consumer for the following.
   A. If the damage was caused by the consumer, then the consumer should cover all expenses in fixing the product, if the product still can't be fixed, we would suggest consumer in buying a brand new product.
   B. Product defect caused under natural use, expenses will be covered by the distributor.
2. Faulty products with expired warranty dates, we would suggest consumer to purchase a brand new products, without undergoing for repairs.

Table A:

Cooler Master Products
Please check your user manual for the exact warranty period terms for products that are not shown below.
For more warranty information, please visit our official website: http://www.coolermaster.com/service/warranty.html

Cooler Master Gaming Peripherals products warranty

Product Name	Warranty Term
Keyboard	2 years

For the most updated information, please visit our official website:
gaming.coolermaster.com
Cooler Master Support: https://account.coolermaster.com/

Make It Yours.



MASTERKEYS PRO L

Intelligent **White LEDs**
Mechanical Cherry MX Switches

MX CHERRY MECHANICAL KEYSWITCH TECHNOLOGY

Uso della tastiera Cooler Master MasterKeys Pro L
Accesso Funzioni avanzate

Proprio come su un computer portatile, premendo il tasto FN, allo stesso tempo, come uno dei tasti F1-F12 consente una seconda funzione programmata per questo tasto.

FN + ESC = Ripristinare profilo predefinito

FN + F1 = Retroilluminazione acceso / spento
FN + F2 = Diminuire la luminosità del LED
FN + F3 = Aumentare la luminosità del LED
FN + F4 = Scambiare modalità del LED

FN + F5 = Frequenza di ripetizione 1X
FN + F6 = Frequenza di ripetizione 2X
FN + F7 = Frequenza di ripetizione 4X
FN + F8 = Frequenza di ripetizione 8X

FN + F9 = Blocco delle finestre
FN + F10 = Registra retroilluminazione LED
FN + F11 = Registra Macro
FN + F12 = Cancella Macro

FN + STAMP = Singolo Macro loop
FN + BLOC SCORR = Ripeti Macro
FN + PAUSA = Infinito Macro Loop

Asia Pacific - Cooler Master Technology Inc.
8F., No. 788-1, Zhongzheng Rd., Zhonghe Dist.,
New Taipei City 23586, Taiwan (R.O.C.)
Tel: +886-2-2225-3517

China - Cooler Master China
Room 2062, Floor 6, No. 421, Weiqing Rd.,
Jinshan District, Shanghai City, China
Tel: +86-21-51872177

Europe - Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC Eindhoven,
The Netherlands
Tel: +31-(0)40-702-0900

North America - Cooler Master NA
4820 Schaefer Ave. Chino CA. 91710, USA
Tel: +1-888-624-5099

P1 = Passare al Profilo 1
P2 = Passare al Profilo 2
P3 = Passare al Profilo 3
P4 = Passare al Profilo 4

FN + Ins = Play/Pausa
FN + Inizio = Traccia successiva
FN + Page Up = Volume sù

FN + Canc = Stop
FN + Fine = Traccia precedente
FN + Page Down = Volume giù

FN + E = Ripristina tutto al default
FN + R = Ripristina profilo al default

FN + Tasti freccia verso il basso / verso l'alto:
accelerare / rallentare gli effetti di illuminazione a LED
FN + Tasti freccia verso la sinistra/ verso destra:
passare al volo ai tasti del ciclo alternativo

Contenuto del pacchetto:

- Tastiera MasterKeys Pro L
- Guida rapida
- Estrattore del tasto
- Cavo intrecciato USB da 1,5 millimetri

* Se la tastiera è collegata alla porta USB 2.0 e non viene rilevata, si prega di utilizzare la porta USB 3.0.

Per ulteriori informazioni, visitate il nostro sito:
http://gaming.coolermaster.com/en/start/

510011810-GP IT
Ver 1.0: 2016/05

© 2016 Cooler Master Technology Inc. All Rights Reserved.
All trademarks are registered to their respective owners.

EN

- Brilliant white LED lighting - Get the brightest of brights with a white, steel backplate that helps the LEDs shine bright and true
- Multiple lighting modes - Customize light modes without software. Preset modes include breathing, wave, and responsive effects
- Cherry MX switches - Guaranteed for 50 million keystrokes, Cherry MX switches give you the tactile preference you desire
- On-the-fly macro and profile support - save macros and settings without hassle
- Sleek, minimalistic design - Refined symmetry and a heavy-weight quality build help keep things clean and simple

RU

- Ярко-белая LED подсветка - самые яркие огни подсветки благодаря белой стальной задней панели, которая делает огни светодиодов еще ярче
- Несколько режимов подсветки - настройте режимы подсветки без программного обеспечения. Предустановленные режимы включают в себя дыхание, волна, и ответный эффекты
- Переключатели Cherry MX - гарантированные 50 миллионов нажатий клавиш, переключатели Cherry MX обеспечивают те тактильные ощущения, которые предпочитаете вы
- Поддержка макросов и профелей на-лету - сохраняйте макросы и настройки без хлопот
- Гладкий, минималистский дизайн - рафинированная симметрия и высокое качество сборки обеспечивают чистый и стильный вид

DE

- Brillantweiße LED-Beleuchtung – Eine weiße Backplate aus Stahl lässt die LEDs besonders hell und gleichmäßig leuchten
- Mehrere Licht-Modi – Passen Sie die Licht-Modi ohne Software an. Zu den voreingestellten Modi gehören Atmung, Welle und auf Tastendruck reagierende Effekte
- Cherry-MX-Schalter – Mit einer garantierten Lebensdauer von 50 Millionen Tastenanschläge geben Ihnen Cherry-MX-Schalter die taktile Präferenz, die Sie sich wünschen
- On-the-Fly Makros und Profile - Makros und Einstellungen können besonders einfach gespeichert werden
- Schlankes und minimalistisches Design – Raffinierte Symmetrie und robuste Qualität sorgen für einen übersichtlichen Aufbau der Tastatur

ES

- Iluminación LED blanca y brillante - Obtenga el más brillante de los brillos con una blanca, placa posterior de acero que ayuda a los LEDs a brillar resplandecientemente
- Múltiples modos de iluminación - Personalice modos de iluminación sin necesidad de software. Los modos predefinidos incluyen breathing, wave, y efectos de respuesta
- Interruptores Cherry MX - Garantizados por 50 millones de pulsaciones, los interruptores Cherry MX le dan la preferencia táctil que desee
- Soporte de macros y perfil On-the-fly - Guarde macros y ajustes sin problemas
- Diseño elegante y minimalista - Simetría refinada y una calidad de construcción de gran peso ayuda a mantener las cosas limpias y sencillas

FR

- Éclairage LED blanc lumineux - Obtenez un éclairage encore plus lumineux grâce à la plaque en acier qui améliore le rendu des LEDs
- Modes d'éclairage variés - Personnalisez les modes d'éclairage sans logiciel. Les modes préréglés incluent des effets de respiration, de vague ainsi que des effets réactifs
- Interrupteurs Cherry MX - Garantis pour 50 millions de frappes, les interrupteurs Cherry MX vous offrent un toucher adapté à vos besoins
- Macros et profils à la volée - auvegardez vos macros et tous vos réglages en toute simplicité
- Design épuré et minimaliste - Une symétrie revisitée et une qualité de fabrication exceptionnelle pour rester simple et efficace

IT

- Brillante illuminazione a LED bianco - Ottieni il più brillante di luci con una piastra bianca di acciaio che aiuta i LED brillare in modo luminoso ed autentico
- Molteplici modalità di illuminazione - modalità di illuminazione personalizzate senza software. Modalità preimpostate includono la respirazione, onda, e gli effetti reattivi
- Cherry MX interruttori - garantiti per 50 milioni di combinazioni di tasti, switch Cherry MX ti danno la preferenza tattile che desiderate
- Macro al-volo e il supporto del profilo - salva macro e le impostazioni senza problemi
- Design elegante e minimalista - Simmetria raffinata e qualità costruttiva al peso massimo aiuta mantenere le cose pulite e semplici

KR

- 화려한 흰색 LED 조명 – LED를 밝고 찬란하게 빛나도록 해주는 흰색의 스틸 백플레이트를 가진 가장 밝은 전조등을 만나보세요
- 다중 조명 모드 – 소프트웨어 없이 라이트모드를 설정할 수 있습니다. 프리셋 모드는 호흡, 웨이브와 반응 효과를 포함하고 있습니다
- Cherry MX 스위치 – 5,000 만 키 입력이 보장된 Cherry MX 스위치는 당신이 원하는 촉각 환경을 제공합니다
- 상황에 맞는 매크로 및 프로파일 지원 – 번거로움 없이 매크로 및 설정을 저장합니다
- 매끈한, 미니멀리스틱한 디자인 – 엄밀하게 다듬어져 균형잡힌 고품질의 제품은 깨끗하고 심플한 상태로 유지시키기 쉽습니다

CHT / CHS

- 獨特LED技術-提供LED更高的亮度，定位鋼板使用置母白烤漆，確保LED更自然光線反射
- 多種燈效模式-通過鍵盤複合鍵就能隨手切換如呼吸，音浪，水波紋等模式，更可軟體即可設定
- 德國原廠Cherry MX 機械式軸體 - 超過5000萬次使用壽命
- 飛梭巨集功能與自訂編組-無需通過驅動儲存，直接在鍵盤操作即可完成
- 時尚,簡約的設計，外觀經典，簡約而不簡單

- LED高亮度，定位钢板使用云母白烤漆，确保LED自然的光线反射
- 多种灯效模式-通过键盘组合键就能实现如呼吸，音浪，涟漪等模式，而无需软件条件
- 德国原厂Cherry MX 机械式轴体 - 超过5000万次使用寿命
- 飞梭宏功能与自定义编组无需通过驱动存储，直接在键盘操作即可完成
- 时尚，简约的设计，外观经典朴实，简约而不简单的经典

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
结构壳体	X	O	O	O	O	O
开关组件 PCB.USB	X	O	O	O	O	O
线 材	X	O	O	O	O	O
螺 丝	X	O	O	O	O	O

O：表示该有害有毒物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。
X：表示该有害有毒物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。
注：本产品95%的部件采用无害无毒的环保材料生产，含有有害有毒物质成元素的部件因全球技术发展水平限制而无法实现有害有毒物质或元素的替代。